



The FRE-2 is not intended to be used for point loading material.  
 The weights given below serve as a guide only and the load should always be distributed.



HAMMER	Distance (cm)	25	35	45	55	65	75	85	95	105	115	125	135
40/50	Load (kg)	200	175	155	135	105	75	60	45	25	10	-	-
56/73	Load (kg)	300	285	250	225	150	100	75	60	50	35	20	10